





Shape and installation dimensions



Safe distance: S1≥30mm, S2≥206

- ① Control power
- ③ manual knob
- ⑤ Source B terminal side
- ⑦ Source A indicator
- ② Selection switch(Auto/manual)
- ④ Source A terminal side
- ⑥ Load side main circuit terminal
- ⑧ Source B indicator

Panel Description



- Note: 1. Solar type: The output power of the inverter reaches 1.5KW to supply power to the AR and AN terminals of the automatic transfer switch.
 2. It is recommended to add overvoltage and undervoltage protectors to the circuit to prevent damage to the automatic transfer switch.